



## C.A.R.E. SELECT MEDIA PLAYER UPDATE INSTRUCTIONS

Enclosed in this package is your C.A.R.E. SELECT update content, contained on SD card. The update process is a simple drive swap that does not require powering off your media player or modifying any settings on your TV.

1. Locate your TV-mounted C.A.R.E. SELECT media player, it will be plugged into an individual TV via HDMI cable. The player will either be mounted on the TV itself or placed nearby.
2. Remove the existing SD card from the port on the front panel of the media player, labeled SD.
3. Insert the new SD card into the SD port. Ensure that the drive is fully inserted into the port (SD will stick out about halfway from the device). There is no need to restart the media player, it will automatically begin playing the C.A.R.E. programming once the SD card is inserted.

Please use the same anti-static packing materials to return the old drive to Healing HealthCare Systems. A return label has been enclosed for your convenience. If you cannot locate the label, or if you have any questions during the card replacement, please contact us at **800-348-0799** or [support@healinghealth.com](mailto:support@healinghealth.com).