



## C.A.R.E. SELECT MEDIA PLAYER UPDATE INSTRUCTIONS

Enclosed in this package is your C.A.R.E. SELECT update content, contained on USB drive. The update process is a simple drive swap that does not require powering off your media player or modifying any settings on your TV.

1. Locate your TV-mounted C.A.R.E. SELECT media player, it will be plugged into an individual TV via HDMI cable. The player will either be mounted on the TV itself or placed nearby.
2. Remove the existing USB drive from the port on the front panel of the media player, labeled USB.
3. Insert the new USB drive into the USB port. Ensure that the drive is fully inserted into the port (USB will stick out slightly from the device). There is no need to restart the media player, it will automatically begin playing the C.A.R.E. programming once the USB drive is inserted.

Please use the same anti-static packing materials to return the old drive to Healing HealthCare Systems. A return label has been enclosed for your convenience. If you cannot locate the label, or if you have any questions during the drive replacement, please contact us at **800-348-0799** or [support@healinghealth.com](mailto:support@healinghealth.com).